

A woman with long dark hair, wearing a white long-sleeved shirt and a dark patterned skirt, is playing a violin. A grey acoustic panel is positioned behind her, partially covering her torso. Three red curved arrows point from the text box to the top edge of the panel. The background is a plain light grey.

assembly instruction
acoustic panel

FOX
RAUMAKUSTIK



BLANK WALL OR CEILING:

- > plasters
- > roughcast
- > concrete
- > lamber/wood

on this note the exact measures



ASSEMBLY OF THE SUBFLOOR:

lamber: ca. 70 x 24 mm

spacerbolt: 6 Stk. 10 x 100 mm

distances/raster: 600 x 600 mm
300 x 300 mm



FINISHED SUBFLOOR



SUBFLOOR BACKFILL WITH:

- > acoustic fleece 20 mm
- > acoustic insulation WDP 50



cut the BARRIER at 45 °



clamp the barrier with 40 MM TACK on the subfloor



fill the tackhead with WAX PUTTY



take a note at the upper edge



stick the ASSEMBLY on the panel



clamp the FIRST PANEL mit 2-3 tack



screw tight the assembly clows with
3 x 20mm SCREWS on the subfloor



repat this step for step (exapt the first panel
is the only one how is clamped with 2-3 tack)



cut the ROUND OFF PROFILE at 45° and put assembly adhesion on them



put the round off profile on the edge



FINISHED ASSEMBLY WALL PANELLING





FOX HOLZ
flooring and object systems GesmbH
Molkereiweg 3
4912 Neuhofen im Innkreis
phone: +43 7752/ 70 222-0
telefax: +43 7752/ 70 222-7
office@foxholz.at
AUSTRIA

www.foxholz.at